

JOB GUIDE 4 Test all fires and smoke

Reference	Title	Frequency
JOB GUIDE 4	Test all fires and smoke	Weekly

Objective:

The objective is to check each fire place in order to ensure a trouble-free operation.

Reference:

- Flame Aviation Instructor manual, chapter 5

Job instructions:

1. Select Automatic Mode on the Settings page of the IOS
2. Select a fire scenario
3. Check for proper and adequate ignition
4. Deselect the fire scenario
5. Repeat this exercise for each fire scenario